

# WASHING INSTRUCTIONS FOR PFANNER FORESTRY & WORK CLOTHES

Wash Power Enhancer | Item 100770

Waterproofer | Art. 101911

1



Highly concentrated liquid Wash Power Enhancer. Excellent for cleaning protective clothing with oil stains. Washing temperatures: 30-40 °C.

2



**Pre-treatment:**

For heavy soiling, it is best to use a spray bottle to apply the undiluted cleaner directly onto the stains and, if possible, let it work overnight in water.

3



Next, remove the stains with a hand brush before washing with functional or colour detergent. **DO NOT** use fabric softener.

4



**Machine wash:**

To ensure that the oil is removed from the washing machine, it is important that heavy-duty detergent **NOT** be used. Dose detergent as usual. For 1 kg dry laundry (1 x 1.6 kg chainsaw protection), put 10 ml of PFANNER Wash Power Enhancer into the detergent compartment for the pre-wash.

**Chainsaw protection:** Start the pre-wash setting at 40 °C and switch off the SPIN-DRY SETTING! The chainsaw protection must not be spun.

**Other forestry & work clothing:** Pre-wash setting at 40 °C.

**Waterproof clothing:** After air-drying outdoors, spray with PFANNER Waterproofer (impregnation spray).

5



After the washing cycle is complete, pull the chainsaw protection into shape and hang to dry.

**PFANNER**  
SIMPLE. SAFE. LIVING.